

INSTRUCTIONS FOR MODEL 90 FRINGER

Description:

The Model 90 Fringer will accept paper strips of widths from 1/4 in. to 3/8 in., and provide a pre-set cut spacing of approximately 1/32 in. The depth of cut will vary from 5/16 in. for a 3/8 in. wide strip to 3/16 in. for a 1/4 in. wide strip. An adjustable guide is provided for use with strips less than 3/8 in. wide. The fringer may be mounted on a wooden base for greater stability during operation.

Operation:

1. Insert the paper strip into the left guide (A), manually feed it under the advance finger (B), through the right guide (C), and past the blade a short distance. Be sure the paper is free of kinks, and there are no obstructions in its path.
2. For strips less than 3/8 in. wide, set the adjustable guide (D) to size slightly greater than the width of the strip.
3. Move the handle the full distance between the upper and lower stops. This is necessary to assure a full advance and cut. The paper is advanced automatically at the beginning of the down stroke.

Maintenance:

The Model 90 Fringer should require minimal maintenance. Occasionally lubricate the advance finger at point (E) with a tiny amount of an automotive type grease. Slight adjustments in cut spacing may be made by loosening the screw at the rear of the fringer and turning the bearing post (F) as required. A clockwise turn decreases the spacing. This is a very sensitive adjustment and is normally done only to take up for wear.

Do not clean by immersion in solvents or water.

