

## INSTRUCTIONS FOR MODEL 45 FRINGER

### Description:

The Model 45 Fringer accepts a folded 3/8 in. wide strip of paper, and provides a pre-set cut spacing of approximately 1/16 in. The cut is made to a depth of .23 in. at an angle of 45°. The fringer may be mounted on a wooden base for greater stability during operation.

### Operation:

1. Evenly fold a 3/8 in. wide strip of paper lengthwise.
2. With the fold to the rear of the fringer, insert the strip into the left guide (A), manually feed it under the advance finger (B), through the right guide (C), and past the blade a short distance. Be sure the strip is tightly folded, free of kinks, and there are no obstructions in its path.
3. Move the handle the full distance between the upper and lower stops. This is necessary to assure a full advance and cut. The paper is advanced automatically at the beginning of the down stroke.

**CAUTION: Avoid operating the fringer without paper in it, as the advance fringer may bind causing damage to the fringer. ALWAYS KEEP PAPER IN THE FRINGER!**

### Maintenance:

The Model 45 Fringer should require minimal maintenance. Occasionally lubricate the advance finger at point (E) with a tiny amount of an automotive type grease. Slight adjustments in cut spacing may be made by loosening the screw at the rear of the fringer and turning the bearing post (D) as required. A clockwise turn decreases the spacing. This is a very sensitive adjustment and is normally done only to take up for wear.

Do not clean by immersion in solvents or water.

