


Quilled Creations™

Quilling Fringer

Instructions

INSERT PAPER HERE



To Load Paper: Use TWEEZERS to help you pull a NEW strip of paper under the SPRING and PUSHER BLADE. Press down on the handle a few times to allow the PUSHER BLADE to advance the paper strip.

To Cut Paper: Press down on the HANDLE to cut the paper strip. The fringer will automatically advance the paper when the next cut is made.

To Adjust Between 1/4" (6 mm) & 3/8" (9 mm)

Width Paper: Loosen the screw that holds the PAPER GUIDE with a screwdriver. Slide it up against the paper's edge. Then secure it in place.



To Adjust Cutting Width: Rotate the "WIDTH" ADJUSTMENT KNOB on the back of the fringer.




To Adjust Cutting Depth: Rotate the "DEPTH" ADJUSTMENT KNOB that is just below the handle.

Fringing Techniques!

GERBERA: Fringe a strip of paper with gradually smaller cuts. Trim part of the paper on an angle. Add a 1/8" strip of paper at the end with the angled cuts. Start rolling from the 1/8" wide paper end.



MUMS & POM-POMS: Fringe a paper strip with deeper cuts.



FLOWER CENTERS: Fringe a paper strip with shallower cuts.



To Replace the BOTTOM BLADE:
The longer sides of this blade are cutting edges (4 cutting edges total). Remove both screws, flip or rotate the blade to a new edge and resecure it with both screws.

This cutting tool is not designed to cut cardstock!
Base includes two mounting holes.

www.quilledcreations.com

© 2005 Quilled Creations, Inc

Patent Pending